video_creator™

VIDEO PROJECTOR CAMERA
CAMÉRA PROJECTEUR
PROYECTOR VIDEOCÁMARA • VIDEO PROJEKTOR
CÂMERA PROJETOR • PROJECTOR VIDEOCAMERA
VIDEOCAMERA PROIETTORE

User Manual • Manuel d'utilisation
Manual de usuario • Benutzerhandbuch
Manual de usuário • Handleiding • Manuale d'uso

8+

Contents • Contenu • Contenido
Inhalt • Conteúdo • Inhoud • Contenuti

1 Video Projector Camera
Caméra Projecteur
Proyector Videocámara
Video Projektor - Câmera projetor
Projector videocamera
Videocamera proiettore

1 Sticker sheet
Planche d'autocollants
Hoja de pegatinas
Bogen Aufkleber
Folha de autocolantes
Stickervel - Foglio di adesivi

1 Micro-SD/TF Card
Carte Micro SD/TF
Tarjeta Micro-SD/TF
Micro SD/TF Speicherkarte
Cartão Micro SD/TF
Micro SD/TF-kaart
Scheda Micro SD/TF

1 USB Cable-C
Câble USB-C
Cable USB-C
USB-C Kabel
Cabo USB-C
USB-C-kabel
Cavo USB-C

Projector handling • Prise en main du projecteur
Sujeción del proyector • Handhabung des Projektors
Segurar o projetor • De projector grijpen • Afferrare il proiettore

To ensure a secure grip on the product, slide your hand underneath the strap, allowing your fingers to access the buttons located on the top and back.

Pour une prise en main optimale du produit, glisse ta main sous la sangle de sorte que tes doigts puissent atteindre les boutons au-dessus et à l'arrière.

Para un agarre óptimo del producto, desliza tu mano bajo el asa de manera que tus dedos puedan alcanzar los botones de arriba y de atrás.

Um das Gerät optimal zu halten, schiebe deine Hand so unter den Halteriemen, dass deine Finger die Tasten auf der Ober- und Rückseite erreichen können.

Para uma pegada ideal no produto, desliza a tua mão por baixo da alça para que os teus dedos possam alcançar os botões superiores e traseiros.

Voor een optimale grip op het product, steek je hand onder de riem zodat je vingers de knoppen aan de bovenkant en achterkant kunnen bereiken.

Per una presa ottimale del prodotto, fai scivolare la mano sotto la cinghia in modo che le dita possano raggiungere i pulsanti superiori e posteriori.

1 • FEATURES

1. Product description

2. Buttons



2 • RECHARGING BATTERY

Built-in battery, rechargeable and non-replaceable.

Note: recharging the battery must be done by an adult.

Connect the projector video camera to a computer (or a 5V power converter) with the provided USB-C cable to recharge the battery.
Lift the rubber cover on the front of the device.
Insert the USB-C cable into the USB-C port of the camera.
Connect the other end of the cable to the computer's USB port (or a 5V power converter). When connected, the projector video camera will automatically power off and the LED light will turn red to indicate charging.
When the device is fully charged, the indicator light turns off. You can then unplug the USB-C cable from the computer.

To extend battery life, you can set the camera to automatically power off after a period of inactivity in the Settings menu.

3 • INSTALLING THE MICRO SD CARD

Make sure the device is switched off.
Lift the rubber cover on the front of the device.
Insert the memory card (included) following the diagram shown.
Replace the cover to protect the memory card.
To remove the memory card, press the card once to eject it.

Note: The micro SD card used must not exceed a maximum capacity of 64 GB.

4 • MODES PRESENTATION

Press and hold the power button to turn on the device.
Discover the 4 main modes of your Projector Video Camera.

RECORDING MODE

The recording mode offers complete freedom to capture both videos and photos, while personalising your media with a range of filters, enabling endless creative possibilities.

Taking Photos / Videos

Press the 📷 button once to take a picture/video.
Long press the 📷 button to switch between camera and video modes.

Add fun filters!

Make your recordings even more special by adding colour filters and fun frames on photos.
To add colour filters or frames, use the < and > arrows.

Continuous shooting and timer

Select continuous shooting and timer options using the ∧ and ∨ arrows.

- 3 or 5 picture shooting.
- Continuous shooting with a 3, 5 or 10-second time-lapse between shots.
- Shooting with 3-second timer.

Press the ↩ button to go back to the normal shooting mode.

GALLERY & PROJECTION FUNCTION

Watch your photos and videos in the gallery mode, either on the screen or by projecting them onto any surface!

Reading files

Long press 🖼 button to enter Gallery. Press ↩ button to exit mode.
The photos and videos can be scrolled through by using the directional arrows (< >).
Press the 🖼 button to play the videos.

Deleting files

Press the ⚙ button on the media you want to delete.
Confirm your choice by pressing > or <, then press the 🖼 button.

Projection function

You can project all your videos and pictures anywhere you want!
Press the 📽 button to activate the projection function.
Press again to switch back to the display on the side screen.

Note: The side screen will turn off when Projection function is activated.

SAFETY WARNINGS: When the projection function is activated:
- Do not point the projection directly at someone's face or eyes.
- Never look straight into the light — even if it doesn't seem very bright.
- Keep a safe distance between the projector and anyone nearby.

IMPORTANT: For an optimal experience, we recommend the following:

- Use the projector in a dark room - the darker, the better!
- Place the projector on a flat, stable surface before turning it on. You can adjust the projection angle using the height-adjustable stand below the product.
- Slowly turn the focus ring to adjust the quality of projection until you have a clear image.
- Make sure nothing is blocking the lens.
- Clean the lens gently with a soft, dry cloth if needed.
- Turn off the projector when you're done to let it cool down.

CONNECT A DEVICE TO THE PROJECTOR

Connect any Apple or Android device and project your screen anywhere – perfect for watching movies or holiday videos! You can easily connect your smartphone or tablet to the Projector Video Camera wirelessly through Wifi.

Note: This toy is intended for domestic use only. This toy is intended to be used only with the parents' phone.

Please find below how to connect, depending on your device (Android or Apple).

Note: The cast function operates through the Miracast protocol, enabling the projector to directly project the content of the device's screen, rather than just a single application.

FOR ANDROID DEVICES:

1. Swipe down from the top of the screen to open the Quick Settings menu.
2. Tap "Screen Cast", "Smart View", or "Wireless Display" (the name may vary depending on your device model).
If you don't see it, you can also go to Settings > Connected Devices > Connection Preferences > Cast (or search for "Cast" in the Settings).
3. The name "Projector" should appear in the list of available devices. Tap on it to connect.
4. Wait a few seconds for the screen to appear on the projector!

Note: On some devices, features like Smart View may allow you to cast only a specific app instead of the entire screen. This depends on the phone's built-in settings and Android version.



FOR APPLE DEVICES (IPHONE OR IPAD):

1. Open the Settings app on your iPhone or iPad, tap **Wi-Fi**. Select the projector's Wi-Fi name (**"Projector"**).
2. Open the **Control Center** (swipe down from the top-right of the screen) and tap **Screen Mirroring** icon.
3. Select your projector's name from the list (**"Projector"**).
4. Your screen should appear on the projector in a few seconds.

Note: If the projection doesn't show up, please check that Wi-Fi is enabled and that the projector is in screen sharing mode.

You can now project all your videos and pictures wherever you want!

Note: To adjust volume when projecting, please use the > & < arrows.

SETTINGS

You can customise every aspect of your device to suit your preferences. Adjust the language, brightness, set the time, choose the photo/video resolution, and enable or disable sleep mode, among other options.

SETTING THE PARENTAL PASSWORD

This password must be set by a parent or guardian. During the first use, an adult must create a 6-digit parental password using the directional arrows and the central button to navigate and confirm each digit. It is designed to protect external access to personal data stored on the device, such as photos and videos, and prevents unauthorized changes to rules and roles.

Press the ⚙ button once to enter Settings mode. Press ↩ to exit mode.

Press the 🖼 button to enter the selected option. Press again to confirm your choice.

TRANSFERRING FILES TO A COMPUTER

Connect the device to a computer with the USB-C cable to copy, transfer or delete the photos / videos of your micro-SD card.



RESET

If the device cannot be turned on/off, it has crashed, is otherwise stuck or frozen, do not disassemble it yourself. Plug the projector video camera to a charging source. Use a pin to press the reset hole for 10 seconds. It will automatically restore to factory settings.

...

CLK 039 - GLO_4
©2025 - Canal Toys®

Canal Toys®
18, rue Curnonsky
75017 PARIS
FRANCE
SAV@canaltoys.fr

Regency House,
York Business Park,
York, YO26 6RW,
GREAT BRITAIN

Designed in France.
Développé en France.
Diseñado en Francia.
Entwickelt in Frankreich.
Concebido em França.
Ontworpen in Frankrijk.
Progettato in Francia.

Made in China. Fabriqué en Chine Fabricado en China.
Hergestellt in China. Fabricado na China. Gemaakt in China.
Prodotto in Cina.

This toy is only to be connected to Class II equipment bearing the symbol:
Ce jouet ne doit être connecté qu'à un équipement de classe II portant le symbole:
Este juguete solo debe conectarse a equipos de Clase II que lleven el símbolo:
Dieses Spielzeug darf nur an Geräte der Klasse II mit dem Symbol angeschlossen werden:
Este brinquedo deve ser conectado apenas a equipamentos de Classe II com o símbolo:
Dit speelgoed mag alleen worden aangesloten op apparatuur van klasse II met het symbool:
Questo giocattolo deve essere collegato solo ad apparecchiature di Classe II recanti il simbolo:

TECHNICAL PARAMETERS • PARAMÈTRES TECHNIQUES
PARÁMETROS TÉCNICOS • TECHNISCHE DATEN • PARÂMETROS TÉCNICOS
TECHNISCHE PARAMETERS • PARAMETRI TECNICI

Screen - Écran - Pantalla Bildschirm - Tela Scherm - Schermo	**2,4 inches, HD 1280*800** - 2,4 pouces 2,4 pulgadas - 2,4 Zoll - 2,4 polegadas 2,4 inch - 2,4 pollici
Projector Video Camera • Power Caméra Projecteur • Puissance Proyector Videocámara • Potencia Video Projektor • Leistung Câmera Video Projetor • Potência Projector-videocamera • Vermogen Videocamera Proiettore • Potenza	7.5W
USB Input Supply Alimentation d'entrée USB Suministro de entrada USB USB-Eingang Entrada USB USB-voeding Alimentazione USB	**DC 5V connected to a SELV.** DC 5V connecté à la source SELV (Safe Extra Low Voltage). DC 5V conectado a un SELV. DC 5V, mit SELV verbunden. DC 5V conectado a um SELV. DC 5V aangesloten op een SELV-bron DC 5V collegato a una sorgente SELV
Wi-Fi – Frequency band Wi-Fi – Bande de fréquence Banda de frecuencia Wi-Fi WLAN – Frequenz Banda de frequência Wi-Fi Wi-Fi – Frequentieband Wi-Fi – Banda di frequenza	2412 - 2472 MHz
Wi-Fi / Power Puissance – Potencia – WLAN Leistung – Potência Vermogen – Potenza	19.81 dBm

01 PET	21 PAP	04 PE-LD
Plastica Plástico	Carta Papel	Plastica Plástico
Blister	Scatola Caixa	Sacchetto di plastica Saco de plástico

RECICLA
RECICLA
FR NOTICE BAC DE TRI
FR DONNEZ OU RECYCLEZ — ASSOCIATION OU MAGASIN OU DÉCHÈTERIE
Adresses sur quefairedemesdechets.fr

FR Cet appareil, ses accessoires, piles et cordons se recyclent — À DÉPOSER EN MAGASIN OU À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.quefairedemesdechets.fr